

FIG. 1

5 ENGINE

6

7 7a 7b 7c

1 2a 2b 2c

3

4

8

9

10

11

12

13

14

15

16

17

18

19

(ENGINE CONTROL SIG.)

INFORMATION ABOUT INPUT TORQUE (ENGINE SPEED, FUEL INJECTION TIME LENGTH)

SPEED-CHANGE CONTROL HYDRAULIC CIRCUIT

CVT CONTROLLER


INHIBITOR SW

ACCELERATOR OPENING SENSOR

(Ppri) (Psec) (Npri) (Nsec)

(SELECTED RANGE SIG.)

(APO)




[illegible]

FIG.3




FIG.4




FIG.5




FIG.6A




FIG.6B




FIG.6C




FIG.6D




FIG.6E

